

Response to Questions from Hardy's Plumbing and Welding, LLC
May 27, 2008

Reference: Toilet Renovations
Florida Supreme Court Building
H+SA #07.114

Question: For all the new trap primers going to the new/existing floor drains, do you want the trap primer line to tie into the floor drain or the p-trap. Please give a detail on correct installation.

Answer: Whichever meets the plumbing code and is the least expensive. Install in accordance with acceptable construction practices.

Question: For the new trap primers, which location would you prefer, above the ceiling installation or below the sink installation?

Answer: Below the sink.

Question: For all the existing showers, do you want new shower trim or new shower valves and shower trim.

Answer: New shower valves and trim.

Question: In the prints/specs there is no specific toilet or urinal, are standard Kohler fixtures ok to use?

Answer: As was stated at the pre-bid meeting, use similar toilets and urinals as those that are existing. Kohler as a manufacturer is acceptable.

Question: For the new hot water going to all the existing lavatory locations, who is responsible for cutting and patching the walls?

Answer: This is a means and methods question, the bidder is responsible for all activities in their project. How they choose to divide the various tasks between their subcontractors is up to them.